

SCHULTZ DP GAUGE With GO NO-GO Scale



The proven and reliable Schultz DP Gauge* is now available with a **GO NO-GO** scale.

This scale simplifies reading the gauge. In this configuration a quick glance of the gauge will verify if differential pressure is in the **GO (safe)** or **NO-GO (danger)** range.

This scale reduces operator work load during fueling operations. Numerical values may be easily forgotten. The GO NO-GO scale counters this. If the operator observes the piston in the **red** zone, differential pressure is above acceptable limits.

3 types of Go No-Go scales are offered as an option to our standard gauge*.

Custom scales can be designed for your own companies Go No-Go DP parameters, call for details.

OPTION I 0-30 psi scale
1-15 **GO** 15-30 **NO-GO**

OPTION J 0-30 psi scale
1-25 **GO** 25-30 **NO-GO**

OPTION K 0-15 psi scale
1-13 **GO** 13-15 **NO-GO**